

Assembly Instruction for TSR-16 Table Slab Roller

Parts list :



1




2





3



4

